

Master Volume Installation Instructions

Parts required:

250KA Dual Potentiometer x 1

2.2M Resistor x 2

Dual conductor shielded wire x approximately 2FT

Step 1: Remove the (2) 220K resistors that are connected to G1 & G2 on layout diagram.

Step 2: Unscrew board from stand-off's. Gently lift board and cut off the wires that are connected to G1 & G2.

Step 3: Unsolder these wires from pin 5 on each power tube socket.

Step 4: Remove the speaker jack that is furthest from the impedance selector switch, and install the Dual 250KA potentiometer.

Step 5: Connect the Master Volume control as shown on the modified layout diagram.